

alliance-users@asim.lip6.fr

overview.pdf

-
-
-
-
-
-
-
-
-
-
-
-
-

•
•
•

•
•
•
•
•
•
•

c-like csh tcsh

```
~alp/addaccu %-) source /etc/profile.d/alc_env.csh
```

sh-like

```
~alp/addaccu %-) source /etc/profile.d/alc_env.sh
```

```
~alp/addaccu %-)
```

alp addaccu %-)

```
~alp/addaccu %-) env | grep MBK
```

```
~alp/addaccu %-) env | grep MBK
MBK_IN_PH=ap
MBK_SCALE_X=100
MBK_CATAL_NAME=CATAL
MBK_OUT_PH=ap
MBK_OUT_LO=vst
MBK_VSS=vss
MBK_C4_LIB=./cellsC4
MBK_VDD=vdd
MBK_TARGET_LIB=\$ALLIANCE\_TOP/cells/sxlib
MBK_IN_LO=vst
MBK_WORK_LIB=
MBK_CATA_LIB=.::/usr/lib/alliance/cells/sxlib:/usr/lib/alliance/cells/dp_sxlib:
/usr/lib/alliance/cells/rflib:/usr/lib/alliance/cells/ramlib:
/usr/lib/alliance/cells/romlib:/usr/lib/alliance/cells/pxlib:
/usr/lib/alliance/cells/padlib
```

MBK

vst

ap

al

sh-like

```
~alp/addaccu %-) MBK_OUT_LO=vst; export MBK_OUT_LO
```

```
~alp/addaccu %-) setenv MBK_OUT_LO al
```